

Fermax Placa Milo Installation and Usage Guide



Date: Thursday, 17 June 2021
Authors: Justin Bateson

Contents

Overview	3
Features	4
Changelog	5
Version 20210610	5
Version 20210609	5
Introduction	6
Configure Device	7
Minimum Configuration	7
Manual Configuration	7
GENERAL	7
SIP	8
SIP TRUNK	8
SIP CALL	9
Licensing	10
Configure Control4	11
Auto Configure the Door Station	11
FAQ	12
What cool things can we do with this driver?	12
What products will this work for?	12
Troubleshooting	13
I can't see the door station on the network	13
SIP Credentials Not Working	13
The door station appears greyed out on the C4 Touchscreen	13

Overview

This driver provides integrators with a driver that configures the Fermax MEET Placa Milo door station to work with with Control4.

With our driver you can configure the door station and Control4's Communication's Agent all from the Properties tab of the driver.

Features

- Control4 OS 3.0 Support
- Configure the door station without accessing the door station's web user interface
- Have both audio and video intercom
- Unlock the door connected to the door station from the Control4 interface
- Select the call group that the door station will call, from within the Properties tab

Changelog

Version 20210610

Added Action to programmatically unlock the door

Version 20210609

Initial release

Introduction

The driver is able to auto configure the Fermax Milo doorstation for a simple setup.

If you have a more complex site, you can manually configure the Fermax door station and the driver. You must take care that the settings in the driver match the configuration of the door station's web ui.

The device comes with the following configuration:

IP address: **10.1.1.2**

username: **admin**

password: **123456**

Configure Device

Minimum Configuration

1. Identify and reserve an IP address via the site's DHCP server
2. Change the network settings such as IP address, Subnet Mask and Gateway of the device
3. Change the default username and password as required
4. Connect door station to the network

Manual Configuration

If you choose not to use the Auto Config tool in the driver then please follow these steps. If you have a pre-existing door station which is configured, you may want to do the config manually.

GENERAL

APARTMENT This should match the apartment and number added in the SIP CALL menu

VIDEO RESOLUTION 320x240 should be fine. 1280x720 might slow the C4 interface down but should still work



DEVICE	GENERAL SETTINGS	
GENERAL	TYPE:	1W PANEL
NETWORK	BLOCK:	1
ACC	APARTMENT:	1
SIP	DEVICE NO.:	1
SIP TRUNK	DEVICE TAG:	(≦16 CHARACTERS)
SIP CALL	LANGUAGE:	ENGLISH
ADVANCED	PANEL VOLUME:	5
PINCODE	DOOR OPEN VOICE:	<input checked="" type="checkbox"/>
RESTORE	VIDEO RESOLUTION:	320x240
	SIP DIVERT MODE:	PARALLEL CALL
	DATE FORMAT:	DD/MM/YYYY
	DATE:	10 / 06 / 2021
	TIME:	21 : 40 : 43
	TIME ZONE:	GMT+01:00
	SAVE	

SIP

SIP SERVER This is usually the IP address of the C4 controller. You can check this address in Composer > Agents> Communication > Advanced tab > IP Address.

It should have **SIP:** in front of the IP Address

DOMAIN This is the same IP Address as the SIP SERVER above

SIP USER This needs to be exactly the same as the setting in the driver's Properties tab

SIP PASS This needs to be exactly the same as the setting in the driver's Properties tab

SIP USER	MEET
SIP PASS	1234



DEVICE	SIP SETTINGS
GENERAL	
NETWORK	
ACC	
SIP	
SIP TRUNK	
SIP CALL	
ADVANCED	
PINCODE	
RESTORE	
	ENABLE SIP: <input checked="" type="checkbox"/> SEARCH SIP STATUS
	SIP SERVER: sip:192.168.1.65
	DOMAIN: 192.168.1.65
	STUN IP:
	STUN PORT: 5060
	H.264: 102
	SIP USER: MEET
	SIP PASS: ●●●●
	CONVERSATION: 120s
	RING TIME: 30s
	<input type="button" value="SAVE"/>

SIP TRUNK

DISABLE SIP TRUNK This has to be unticked



- DEVICE
- GENERAL
- NETWORK
- ACC
- SIP
- SIP TRUNK
- SIP CALL
- ADVANCED
- PINCODE
- RESTORE

SIP TRUNK SETTINGS

ENABLE SIP TRUNK:

URL:

SIP CALL

The only requirement here is that the APARTMENT and NUMBER in the table matches the GENERAL menu settings

NUMBER This is the group or device that the door station will call when the button is pressed. This should take the form of **sip:All@192.168.1.65**

Note: This is case sensitive!



- DEVICE
- GENERAL
- NETWORK
- ACC
- SIP
- SIP TRUNK
- SIP CALL
- ADVANCED
- PINCODE
- RESTORE

SIP CALL SETTINGS

APARTMENT:

NUMBER:

DELETE:

APARTMENT	NUMBER	APARTMENT	NUMBER	APARTMENT	NUMBER
1	sip:rrr@172.16.16.21				

Licensing

Fermax will provide you with a unique Licence Key.

You will need to provide Fermax with the MAC address of the Control4 controller that the driver will be used on.

Enter the Licence Key provided by Fermax into to the Properties field and press **Set**

When you have a valid code entered, the Licence Status property will change to ACTIVATED

Configure Control4

*Make sure you have completed the licensing steps before proceedi

1. Open Composer and Search for **Fermax**
2. Add the driver **Fermax Placa Milo Door Station Driver** to your project
3. Update the following as required:
 - **IP Address** The IP address of the door station
 - **HTTP Port** Leave as default
 - **Username** This is the username for the door station web ui
 - **Password** This is the password for the door station web ui
 - **SIP SERVER** This will auto populate with the IP of Control4's SIP server which shouldn't need changing
 - **SIP USER** This can be anything you want. You can also leave the default value as well
 - **SIP PASS** This can be anything you want. You can also leave the default value as well
 - **Intercom Group to Call** This will auto populate with a list of all the available groups. Choose the group you would like the door station to call
 - **Apartment Number to Dial** This will add the number to the APARTMENT and NUMBER list in the web ui's SIP CALL menu

Auto Configure the Door Station

It is possible to configure the door station once it is on the network. If you haven't made any changes to the door station's configuration you can take the following steps

1. Select the **Actions** tab
2. Click **Auto Configure**
3. Now select the Intercom proxy (which is the 2nd proxy attached to the driver)
4. Confirm that the **User Name:** field matches the **SIP USER** field in the **Properties** tab
5. Tick **Use Custom Button 1** and rename it appropriately. *this is what users will select to unlock the door*
6. Now refresh the Navigators (**File > Refresh Navigators**)
7. Now refresh the SIP server (**Agents > Communication agent > Advanced tab > Refresh Gateway button**)

FAQ

What cool things can we do with this driver?

- The driver's Auto setup functionality makes configuration of the door station and Control4 quick and easy.
- The door station can unlock the door from the Control4 user interface

What products will this work for?

This will work with Fermax's range of Milo door stations

Troubleshooting

I can't see the door station on the network

The door station only has statically defined network properties.

The device comes with the following configuration:

IP address: **10.1.1.2**

username: **admin**

password: **123456**

You'll need to change the IP address to match a valid, and DHCP reserved, IP address on the network that the Control4 controller can reach.

SIP Credentials Not Working

Be aware that the SIP credentials are case sensitive and you should avoid any special characters or spaces

The door station appears greyed out on the C4 Touchscreen

To fix this, in the driver you can select the Actions tab > Idle State